

User Manual



Brief introduction

This manual will guide you on how to use the SAILPROOF SP10 tablet to get you started.

1. Ready to start

After unpacked, you will see the following standard items:


1. SAILPROOF SP10W Rugged Tablet
2. Universal Power Adapter (UK, USA, Australia/NZ and EU compatible)
3. 12v cigarette-lighter power adapter
4. USB-A to USB-c cable
5. Hand Straps
6. Screws (4 pieces)
7. Windows 10 PRO official DVD with license

Please check all items in detail.

2.1. Install the SIM Card

(Note: check the section 2.7 to locate the right port)

The card is a **Micro-SIM** size (intermediate size between SIM and Nano-SIM). Open the cap and insert the SIM card according to the following arrow direction (as shown below). You will hear a click when it's locked. Push it down again to unlock.



BE CAUTIOUS when inserting a SIM card or memory card and follow exactly the instructions in our manual.

A card slipped upside down (be careful: the picture of the operating instructions shows the BACK SIDE of the tablet) or crooked may damage the contacts of the port. This is not covered by the guarantee. In addition, the port is a bit large and if you force the insertion of the card obliquely, it could slip inside the tablet.

2.2. Install the SD Card

(Note: check the section 2.7 to locate the right ports)

Open the cap and insert the SD card according to the following arrow direction (as shown above). You will hear a click when it's locked. Push it down again to unlock.

Note:

The maximum size of the SD card is 256 GB.

2.3. Connect Power

Please use the power adapter provided with this product only. Using other power adapters may damage your computer.

Note:


The tablet is shipped to you in a power-saving mode, which protects the battery from charging or discharging. When you install the battery for the first time and connect your tablet to AC power, the battery will automatically exit this mode and you will be ready to use.

Connecting the power adapter will start charging the battery. AC power must be activated when power is turned off.


Plug the DC power cord of the power adapter into the power jack of the SAILPROOF SP10 tablet.

2.4. SAILPROOF SP10 Tablet On/Off Key

Press the button (1) to switch on/off the tablet.




2.5. Front Components




1. Touch screen: display tablet information and receive touch.
2. Microphone: receives sound for recording.
3. Front camera.
4. Charging indicator.
When SAILPROOF SP10 tablet is charging, it flashes red;
When SAILPROOF SP10 tablet is in sleep mode, it changes to fixed red.

2.6. Back Components




1. Speakers: outputs sound from the tablet.
2. Rear Camera: let you use the built-in photography functions of the tablet.
3. Flash: supplements light when taking pictures.
4. Screw holes to install the hand strap by fastening screws or a standard-compliant VESA (100*200 mm.) mount.
5. Slides to lock/unlock the removable battery.
6. Removable battery.

2.7. Right side




1. RJ-45 port LAN Ethernet 1000 mbps.
2. RS-232 COM port.
3. SD card holder.
4. SIM card holder.
5. Not in use.

2.8. Left side




1. HDMI port: connects an HDMI monitor or TV.
2. Composite audio port: connects to headphones or external speakers with amplifier.
3. USB-c port: USB-2.0, connects to USB devices, use as OTG port or to charge the battery.
4. USB-A port: USB-2.0, connects to USB devices, such as USB flash drives, keyboards, mouse, etc.
5. Power jack: Connects to AC power adapter.

2.9. Top side



1. Custom Keys.
2. Power on&off key (POWER).
3. Volume: up / down key.

2.10. Bottom side



1. Base fixing holes
2. Pogo pin docking station socket which connects to the docking station (optional)

3.1. Connect Audio equipment

For better audio quality, you can connect an external audio device. Your SAILPROOF SP10 tablet is equipped with a composite audio port in the form of a 4-pole TRRS 3.5mm specification and can be connected to a compatible headset.

Safety Warning:

To avoid possible hearing loss, please do not listen at high volume for long periods of time.

3.2. Connect the HDMI display

If you want to use a larger screen for higher resolution, you can connect an external display to your SAILPROOF SP10 tablet. Your SAILPROOF SP10 tablet has an HDMI port, and the HDMI (High-Definition Multimedia Interface) audio/video interface can transmit uncompressed digital data for true high-definition quality.

In the default state, the connected display will respond.

3.3. Battery

When charging, the light flashes red.

When charging is complete, the light changes to fixed red.

Battery Guidelines

When using the battery, please try to fully charge the battery and recharge it once. This will prevent damage to the battery.

Batteries are consumables; the following actions will shorten their service life:

- Charge the battery frequently
- Use, charge or store batteries in high temperature environments

In order to avoid accelerating the aging of the battery and prolong its service life, the number of charging times should be minimized, and the internal temperature of the battery should not be constantly raised.

- Optimally charge the battery in a temperature range of 10°C ~ 30°C (50°F ~ 86°F). - Higher ambient temperatures will cause the battery temperature to rise.
- Avoid charging the battery in closed cars and hot weather.
- It is recommended that you do not charge the battery multiple times a day.
- It is recommended that you charge the battery when the SAILPROOF SP10 is turned off.

When using battery power in an extremely low temperature environment, the operating time may be shortened and the displayed value of the power may be incorrect. This phenomenon results from the chemical characteristics of the battery.

It is recommended that the proper battery operating temperature be maintained at -10° C ~ 50° C (14° F ~ 122° F).

Do not store the machine for more than six months without charging it.

3.4. Power Adapter

The power adapter is only for your SAILPROOF SP10 tablet. If it is used for other purposes, it may damage the connected appliances or adapters. The power cord attached to the power adapter is in accordance with the specifications of the place of purchase. To use this SAILPROOF SP10 tablet abroad, consult your dealer for a suitable power cord.

If you want to unplug the power adapter, you must first unplug the power plug on the wall, and then unplug the power connector on the tablet, otherwise, the SAILPROOF SP10 tablet and adapter will be damaged by external voltage shock.

When unplugging, do not pull the electric wire, you should pull it out by holding the plug with your hand.

The adapter operates in a voltage range of 100 to 240 V AC.

When mains power is not available, it is recommended to use the supplied USB-A cable to DC jack to get the best performance. of the charger. Alternatively, the battery can be charged using the USB-c port. Note that the charging time will then depend on the quality of the cable and the capacity of the charger. Always choose a high quality cable. Some chargers/ cables will limit the load to 0.5 A.

Battery Charging

The battery can be recharged between 0° C (32 ° F) and 45° C (122 ° F). When the battery temperature is outside this range, charging will not start. When the battery temperature meets the conditions, charging is performed automatically. During the charging process, do not unplug the power adapter when it is not fully charged, otherwise, the battery will be insufficiently charged.

- The high temperature protection mechanism of the battery will limit the maximum battery capacity to 80% of the total capacity at high temperatures. At high temperatures, 80% of the charge is equivalent to fully charging the battery.
- Even if the battery is fully charged (100%), the battery charge may decrease automatically due to self-discharge characteristics (0.21% per day). This occurs whether or not the battery is mounted on a tablet.
- A full charge takes about 5 hours when the tablet is turned off or about 6 hours when the tablet is turned on (may take longer at low temperatures).

Note: Do not unplug and connect the power adapter immediately after the battery is fully charged. The battery may be damaged as a result.

4. Water resistance

The SAILPROOF SP10 tablet is compliant with an IP67 rated. In order to guarantee optimal use and water resistance, ensure that all the rubber plugs on the ports are correctly sealed. Never open these rubber plugs in the water or a very humid environment.

When the tablet gets wet with salted or chlorine water, it's strongly recommended to rinse it with tap water, and then dry it thoroughly with a soft, clean cloth. Dry carefully plugs and connectors.

Always check that plugs are free of debris and not damaged when you open or close them.

5. Recycling

All electrical and electronic products, batteries, and accumulators must be taken to separate collection at the end of their working life. This requirement applies to the European Union. Do not dispose of these products as unsorted municipal waste.

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials.

6. Reservation

The content of this document is presented as it currently exists. SAILPROOF does not provide any explicit or tacit guarantee for the accuracy or completeness of the content of this document, including, but not restricted to, the tacit guarantee of market suitability or fitness for a specific purpose unless applicable laws or court decisions make liability mandatory. SAILPROOF reserves the right to make changes to this document or to withdraw it any time without prior notice. Changes, errors and misprints may not be used as a basis for any claim for damages. All rights reserved.

SAILPROOF cannot be held responsible for any data or other loss and direct or indirect damages caused by any improper use of this device.

7. Specifications

System: Windows 10 PRO with active license

10 inch screen – Brightness: 850 cd/m2 – Gorilla Glass 3rd generation – Antiglare coating

CPU: INTEL Z8350 1.44~1.92 Ghz

4GB RAM + 64GB ROM

Camera : rear 5 million pixels autofocus, front 2 million pixels fixed focus

Battery: Li-ion 10,000 mah

WiFi 802.11 (a/b/g/n/ac) 2.4 + 5.8Ghz

Bluetooth 4.2 (BLE)

GNSS: Ublox M8n chip – GPS + GLONASS + Galileo

2G/3G/4G (GSM: B3/B8 – WCDMA: B1/B5/B8 – LTE-FDD: B1/B2/B3/B5/B7/B8/B20/ – LTE-TDD: B38/B40/B41)

MicroSD card port (maximum capacity: 256 Gb)

SIMcard port (micro-SIM size)

Ports:

- USB-C (OTG+charge),
- USB-A,
- Mini HDMI,
- Ethernet RJ 45 1000 mbps,
- RS 232
- POGO pin,
- DC jack

Charge: DC jack (5V - 3A) or USB-c (5V - 0.5 to 2.0A)

Headphone: 3.5mm jack

Operating temperature: -10 ~50°C (storage temperature -30 ~70°C)

Size: 274*181*23 mm

Weight: 1150 g

IP67 certified

MIL-STD-810G certified. Drop-test: 1.2m

8. EU – Declaration of Conformity

Reference: ES200902016E / 25 Nov 2020 / Ver. 1.0.

Standards

Article 3.1(a) Health & Safety

EN 50663:2017

EN 62479:2010

EN 62368-1:2014+A11:2017

Article 3.1(b) Electromagnetic Compatibility

EN 301 489-1 V2.2.3

EN 301 489-3 V2.1.1

EN 301 489-17 V3.1.1

EN 55032:2015

EN 55035:2017

EN 61000-3-2:2014

EN 61000-3-3:2013

Article 3.2 Effective Use of Spectrum

EN 300 328 V2.2.2:2019

EN 301 893 V2.1.1:2017

EN 300 440 V2.2.1:2018

9. Terms of Warranty

Your tablet, the battery and the accessories are all guaranteed any factory defect or malfunction that may arise when use of the tablet is normal. These are under warranty for a period of twenty-four months from the date of purchase, which should be shown of your original invoice received when the product was purchased.

Please bear in mind, this warranty fails to cover any of the following:

- Faults or damages that you declare after the warranty period has ended.
- Any repairs that are unauthorized by the manufacturer.
- The tablet of a customer that has been modified or that has modified the software provided by the manufacturer.
- Damages caused by the customer incorrectly inserting the port caps, an accessory that is essential for ensuring the product remains water resistant.
- Damages that occur through accidents, weather, fire, chemicals or improper use and maintenance of the product or any accessories. This includes screen breakage, dirt trapped in the device, damage caused by prolonged exposure to liquid or failure to comply with the care instructions that are included in the user guide provided.
- Any normal wear and tear of any kind that arises after the purchase of the product including scratches, scuffs, scrapes and any general damage to the device that do not affect its ability to function.

10. Support

For any technical questions, please open a ticket on our website (contact page) or send an email to support@sailproof.shop